



A properly done crown is formed and cast in place. Notice the sleeve of insulation which provides an expansion joint between the tile and the finished crown.

Finished crown with silicone sealing the expansion joint.



Drip edge is cast into bottom edge of crown to divert rain off brick.

Notice 1 1/2" overhang which provides good water shed to the top of the chimney.



Photos by Top Hat Chimney Sweeps
PO Box 370, Plymouth, IN 46563 (574) 930-5858
Email: TopHatCS@TopHatCS.com
www.TopHatCS.com